



## ACCESSORY STATION



**Tools Required**  
Allen key (supplied)



1

Use the Allen key to remove the two bolts from the pre-assembled Accessory Station and separate the two halves



2

Align the two parts of the Accessory Station over the lower section of the handle (fig.1 and 2)



3

Insert the bolts into the fitting holes (fig.3)



4

Turn the Allen key clockwise to tighten both bolts (fig.4)



5

Ensure both top and bottom bolts are tightened sufficiently to hold the Accessory Station in place and prevent movement



6

The assembled Accessory Station should now be successfully fitted to the handle as shown (fig.5)