

SCORECARD HOLDER

No Tools Required



1 | Align the Scorecard Holder and fitting bolt as shown (fig.1)



2 | Insert the fitting bolt through the Scorecard Holder and into the Accessory Station (fig.2)



3 | Adjust the Scorecard Holder to the required angle and tighten the bolt fully to prevent movement during use (fig.3)



4 | To insert your scorecard, simply lift where arrow indicates (fig.4)

