

QB2 Push Cart Instruction Manual





REGISTERUNLINE

www.motocaddy.com/warranty

Visit www.motocaddy.com/instructions for other Motocaddy instructions including translations

SERIAL NUMBER / EQUIPMENT OVERVIEW

Locating your Serial Number

The serial number is located inside the Accessory Compartment on the handle and is required when registering your warranty online. Please ensure you retain the packaging in case you need to return your product for any reason. A proof of purchase must be retained in case you require servicing during the warranty period.

Equipment Overview

- 1. Ergonomic Handle
- 2. Scorecard Holder / Accessory Compartment
- 3. Umbrella Holder* attachment
- Drink Holder* / Rangefinder* attachment
- 5. Under Handle Net
- 6 Device Cradle* attachment
- 7. Upper Release Lever
- 8. Upper Bag Support
- 9. EASILOCK® Lower Bag Support
- 10 Front Wheel
- 11. Rear Wheels
- 12. Rear Wheel Ouick Release Buttons
- 13 Lower Release Lever
- 14. Foot Parking Brake Pedal



Attaching the Rear Wheels

The trolley has no definitive left or right wheel. To attach the rear wheels:

- 1. Place the QB2 face down on a dry, clean, flat and soft surface (fig. 1)
- 2. Push and hold down the Quick Release Button (fig. 2) while sliding the wheel axle into the wheel housing as far as it will go (fig. 3)
- 3. Release the Quick Release Button and pull the wheel out slightly to lock. An audible 'click' confirms the wheel is in the correct position
- 4. Repeat the process for both rear wheels

IMPORTANT - Always ensure the surface (Step #1 above) is clean, dry and soft to avoid damage to the trolley.

Using the Parking Brake

Fig 1

The QB2 includes a foot-operated parking brake to hold the trolley in position while you play your shot. Always ensure the trolley has completely stopped moving before applying the parking brake. Step on the Brake Pedal (fig. 4) and release your foot to engage the parking brake. Repeat these steps to release the parking brake.

IMPORTANT - Attempting to apply the brake while the trolley is still in motion may damage the QB2 and invalidate the warranty.









Fig 2

Fig 3

Fig 4

UNFOLDING / HANDLE HEIGHT

Unfolding your Trolley

We recommend attaching the rear wheels before unfolding your trolley (see page 3).

- 1. Position the trolley as shown in fig. 1 and unlock the Upper Release Lever (fig.1 inset)
- 2. Lift the handle into the desired position (fig. 2) and resecure the Upper Release Lever (fig.2 inset)
- 3. Position the trollley as shown in fig. 3 and unlock the Lower Release Lever (fig. 3 inset)
- 4. Lift the frame up and back (fig. 4) the front wheel will automatically unfold. You may need to lift the upper bag support slightly
- 5. Once the trolley is fully unfolded (fig. 5), resecure the Lower Release Lever (fig. 5 inset)

Adjusting the Handle Height

The QB2 offers a wide range of different handle heights to suit all golfers. To adjust the handle height, unlock the Upper Release Lever (fig. 1 inset), move the handle into the desired position and resecure the Upper Release Lever.



Folding your Trolley

- 1. Position the trolley as shown in fig. 1 and unlock the Lower Release Lever (fig.1 inset)
- 2. Push the frame forwards and down (fig. 2) the front and rear wheels will fold underneath
- 3. Once fully folded (fig. 3), resecure the Lower Release Lever (fig. 3 inset)
- 4. Unlock the Upper Release Lever (fig. 4 inset) and fold the handle down (fig. 4)
- 5. Once the trolley is fully folded (fig. 5), resecure the Upper Release Lever (fig. 5 inset)

The folded QB2 can be stored in a number of positions depending on available space and preference. If stored in the folded upright position (fig. 5), the trolley should rest on the upper bag support. Take care not to damage the upper bag support.

Once folded, the QB2 can be safely carried using the trolley handle or upper bag support.

IMPORTANT - Ensure any fitted accessories are removed prior to folding to prevent damage to the trolley and accessories.



LOWER BAG SUPPORTS

Lower Bag Support with EASILOCK® Bag


All Motocaddy trolleys are fitted with the EASILOCK® bag attachment system. This securely attaches the bag, reduces twisting and removes the need to use a lower bag strap.


- 1. If using an EASILOCK® compatible bag, please ensure that the supplied pins are fitted to the bag base (fig. 1)
- 2. If attached, remove the two lower bag support elastic straps by pressing and holding the back of the clip before pulling outwards (fig. 2)
- 3. Align the cut out on the bag base with the lower bag support platform to align the bag pins with the holes on the trolley (fig. 3)
- 4. Lower the bag until the pins locate with the two holes. You should hear a positive "CLICK" as the bag locks into position

Lower Bag Support with Non-EASILOCK® Bag


If you are using a non-EASILOCK® golf bag, please do not remove the two lower bag support elastic straps:

- 1. Position your bag so it is resting on the lower bag support platform and in the cradle of the upper bag support
- 2. Stretch the lower bag strap around the bag base and loop the rounded bar underneath the bag support hook (fig. 4)









 $\operatorname{Fig} 1 \hspace{1cm} \operatorname{Fig} 2 \hspace{1cm} \operatorname{Fig} 3$

Fig 4

UPPER BAG SUPPORTS / ADJUSTING THE BAG SUPPORTS

Upper Bag Supports


The upper bag support straps are secured in the same way as the lower straps using the following steps:

- 1. Stretch the elasticated strap around the bag & loop the rounded bar underneath the hook (fig. 1)
- 2. Position the two placement straps centrally on your golf bag (fig. 2)

Adjusting the Bag Supports

The bag support straps are manufactured from elasticated material to allow your golf bag to be held tightly in position. The strap should be adjusted to be reasonably tight around the golf bag:

- 1. Unclip the elasticated straps from the housing by pulling outwards in the direction shown (fig. 3)
- 2. Move the bar as required to tighten or loosen the strap fitting. Pulling the bar downwards will tighten, upwards will loosen (fig. 4)
- 3. Ensure that the straps are clipped back into the housing before use (fig. 5)





Motocaddy Ltd, Units 15 - 18 Stansted Distribution Centre, Start Hill, Great Hallingbury, Hertfordshire, CM22 7DG, United Kingdom

+44 (0)1279 712 370

info@motocaddy.com

www.motocaddy.com

MC.25.156.001